

"My fireplace doesn't work?" Answer - besides replacing the batteries in the remote also replace the batteries in the box located at the bottom of the fireplace.